

Help Manual Speed Sensor

- 1. Replace controller.
- 2. If the problem is still not resolved, replace the hubmotor.